

Архангельск (8182)63-90-72
Астана (7172)727-132
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06

Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81

Киргизия (996)312-96-26-47

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16

Россия (495)268-04-70

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13

Казахстан (772)734-952-31

Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

www.panblast.nt-rt.ru | | pav@nt-rt.ru

Технические характеристики на тележки для внутренней очистки труб КОМПАНИИ **PanBlast**



Tornado Tool Carriages



Note: The photograph above shows the Tornado Tool Carriage with the Tornado tool installed. The Tornado tool itself is not included with this carriage kit and needs to be purchased separately, refer to **CAT-1003 -01**(or **BAC-BA-0170-00**) for details on the Tornado tool.

Complementary Products



BP600-3 Blast Pot



Corsa II Valve



ConeBlast Tools



Whip Check Cables



SideWinder Blast Nozzles



Couplings & Nozzle Holders



Blast Hoses



Kombi II Remote Valve



Product Features

PanBlast™ Tornado Internal Pipe Blasting Carriage Sets allow fitting of internal blasting tools to various pipe diameters.

Sets available (size ranges when combined with PanBlast™ Tornado Blast Tool):

PanBlast™ Small Range Scissor Carriage Set, for internal pipe diameters ranging from 203 mm to 431mm (8" to 17").





PanBlast™ Mid Range Carriage Set, for internal pipe diameters ranging from 304 mm to 914 mm (12" to 36").

PanBlast™ Large Range Carriage Set, for internal pipe diameters ranging from 1016 mm to 1524 mm (40" to 60"). (with optional Large Rotating Head)

- ▶ Fully adjustable to a specific range of pipe diameters.
- ▶ Centers the blasting tool for optimum blasting coverage.
- ▶ Optional large rotating head available with Large Range Set.

Common Applications

- ▶ Centering of internal pipe blasting tool for optimum coverage.
- ▶ Adapting internal pipe blasting tools to various pipe diameters.



All data and information subject to change without prior notice. Brochure reference CAT-1004-01-00

Component Highlights



| Stock Code | Description | Weight | Include Items |
|----------------|--------------------------------------|---------------------|---------------|
| BAC-BA-0151-00 | Tornado Small Range Scissor Carriage | 3.15 kg (7.00 lbs) | 1 |
| BAC-BA-0164-00 | Tornado Mid Range Carriage Set | 9.10 kg (20.00 lbs) | 2 |
| BAC-BA-0165-00 | Tornado Large Range Carriage Set | 9.60 kg (21.16 lbs) | 3 |
| BAC-BA-0166-00 | Tornado Mid Range Legs Set | 6.92 kg (15.26 lbs) | 4 |
| BAC-BA-0167-00 | Tornado Large Range Legs Set | 7.42 kg (16.36 lbs) | 5 |

Архангельск (8182)63-90-72
Астана (7172)727-132
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06

Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81

Киргизия (996)312-96-26-47

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16

Россия (495)268-04-70

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13

Казахстан (772)734-952-31

Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

www.panblast.nt-rt.ru | | pav@nt-rt.ru