

Архангельск (8182)63-90-72
Астана (7172)727-132
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06

Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81

Киргизия (996)312-96-26-47

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16

Россия (495)268-04-70

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13

Казахстан (772)734-952-31

Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

www.panblast.nt-rt.ru | | pav@nt-rt.ru

Технические характеристики на аксессуары, форсунки шайбы, соединительные прокладки и стопорные штифты компании **PanBlast**



Nozzle Washers



Complementary Products



Nylon Nozzle Holders



Aluminium Nozzle Holders



Nylon Couplings



Blast Hoses



Steel Couplings



AirFlo Pneumatic Handle



ABN-S Blast Nozzles



ABN Blast Nozzles




Product Features

PanBlast™ Rubber Nozzle Washers provide a seal between the rear face of the blast nozzle and nozzle holder. Correct sealing between the nozzle holder and blast nozzle is vital to prevent premature wear of both the nozzle and holder.

- ▶ Molded natural rubber.
- ▶ Shore hardness of 65 – 70.
- ▶ 4 sizes to fit all PanBlast™ nozzle holders.
- ▶ Suitable for use with most OEM nozzle holders.

Common Applications

- ▶ On site industrial and commercial blasting.
- ▶ Blast and painting contractor yard work.
- ▶ Blast room applications.
- ▶ In situ blasting in shipyards and slipways.



BAC-NZ-PB-0029



BAC-NZ-PB-0030



BAC-NZ-PB-0031



BAC-NZ-PB-0032

Stock Code	Description	To Suit Nozzle Holder	To Suit Hose O.D.	To Suit Nozzle Entry Size
BAC-NZ-PB-0029	RNW-1 Nozzle Washer - 10PCS	NNH-0 (BAC-NZ-PB-0021)	Φ28 mm (1-1/8")	13 mm (1/2")
		ANH-1/2 (BAC-NZ-PB-0025)	Φ34 mm (1-5/16")	
BAC-NZ-PB-0030	RNW-25 Nozzle Washer - 10PCS	NNH-1/2 (BAC-NZ-PB-0173)		Φ38 mm (1-1/2")
		NNH-1 (BAC-NZ-PB-0022)		
		NNH-2 (BAC-NZ-PB-0023)		
		NNH-3 (BAC-NZ-PB-0024)		
BAC-NZ-PB-0031	RNW-32 Nozzle Washer - 10PCS	NNH-1/2 (BAC-NZ-PB-0173)	Φ34 mm (1-5/16")	32 mm (1-1/4")
		NNH-1 (BAC-NZ-PB-0022)	Φ38 mm (1-1/2")	
		NNH-2 (BAC-NZ-PB-0023)	Φ48 mm (1-7/8")	
		NNH-3 (BAC-NZ-PB-0024)	Φ55 mm (2-3/16")	
BAC-NZ-PB-0032	RNW-2 Nozzle Washer - 10PCS	ANH-1 (BAC-NZ-PB-0026)	Φ38 mm (1-1/2")	25 mm (1")
		ANH-2 (BAC-NZ-PB-0027)	Φ48 mm (1-7/8")	



Coupling Gaskets and Locking Pins



Product Features

PanBlast™ Coupling Gaskets are designed to fit the recess within hose and blast pot couplings and provide a positive seal between the connections. Locking pins are used to secure the connection between couplings for safety.

- ▶ Shore hardness of 70-75 for a pliable, yet durable seal.
- ▶ 6 sizes available to suit SHC and NHC connectors.
- ▶ Supplied in packs of ten (10) pieces.

Common Applications

- ▶ Gasket replacement for PanBlast™ blast host and pot connectors.
- ▶ Gasket replacement for most OEM connectors.

Complementary Products



Blast Hoses



Twinline Hose



Nylon Couplings



Steel Couplings



Nylon Nozzle Holders




QuikStop IIS Pneumatic Handle



Aluminum Nozzle Holders



ATN Blast Nozzles



BAC-HC-PB-0015



BAC-HC-PB-0016



BAC-HC-PB-0017



BAC-HC-PB-0018



BAC-HC-PB-0019



BAC-HC-PB-0059



BAC-HC-PB-0023



BAC-HC-PB-0024

Stock Code	Description	To Suit Coupling	To Fit Hose OD	Thread Size	Lock Pin To Suit
BAC-HC-PB-0015	BCG-0 Coupling Gasket	SHC-0 (BAC-HC-0088-00)	28 mm (1-1/8")		BCP-1 (BAC-HC-PB-0023)
		STC-0 (BAC-HC-0084-00)		13 mm (1/2")	
BAC-HC-PB-0016	BCG-1/2 Coupling Gasket	SHC-1/2 (BAC-HC-0090-00)	34 mm (1-5/16")		
		STC-1/2 (BAC-HC-0086-00)		13 mm (1/2")	
		NHC-1/2 (BAC-HC-PB-0054)	34 mm (1-5/16")		
		NTC-1/2 (BAC-HC-PB-0057)		13 mm (1/2")	
BAC-HC-PB-0017	BCG-1 Coupling Gasket	SHC-1 (BAC-HC-0082-00)	38 mm (1-1/2")		
		SHC-2 (BAC-HC-PB-0014)	48 mm (1-7/8")		
		SHC-3 (BAC-HC-0092-00)	55 mm (2-3/16")		
		STC-1 (BAC-HC-0080-00)		32 mm (1-1/4")	
		STC-2 (BAC-HC-0105-00)		38 mm (1-1/2")	
BAC-HC-PB-0018	NCG-1 Coupling Gasket	NHC-3/4 (BAC-HC-PB-0051)	34 mm (1-5/16") ID 19 mm (3/4")		
		NHC-1 (BAC-HC-PB-0001)	38 mm (1-1/2")		
BAC-HC-PB-0019	NCG-2 Coupling Gasket	NHC-2 (BAC-HC-PB-0002)	48 mm (1-7/8")		
		NHC-3 (BAC-HC-PB-0003)	55 mm (2-3/16")		
		NHC-4 (BAC-HC-PB-0039)	60 mm (2-3/8")		
		NTC-1 (BAC-HC-PB-0009)		32 mm (1-1/4")	
BAC-HC-PB-0059	NCG-1-25 Coupling Gasket	NHC-1-25 (BAC-HC-PB-0060)	38 mm (1-1/2") ID 25 mm (1")		NCP-1 (BAC-HC-PB-0024)

Архангельск (8182)63-90-72
Астана (7172)727-132
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06

Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81

Киргизия (996)312-96-26-47

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижегород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16

Россия (495)268-04-70

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13

Казахстан (772)734-952-31

Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

www.panblast.nt-rt.ru | | pav@nt-rt.ru